

Installation Instructions

THERMAL PIN PACKET - 744F688

For Pairs of Doors with "Less Bottom Rod"

Used on Fire Rated Doors for:

ED5470B SVR Exit Devices

ED5860B CVR Exit Devices

FM547A

02/08

(617416047)

1. Drill 5/8" diameter hole as shown in "active" leaf of door edge. Install Cap Plug.

2. Drill 9/16" diameter hole as shown in "inactive" leaf of door edge.

3. Install Thermal Pin and Sleeve.

a. Metal Doors:

Insert Sleeve into "inactive" leaf of door edge.

Insert Thermal Pin into Sleeve.

Using wood block as spacer, tap Thermal Pin and Sleeve into 9/16" hole in door edge with hammer.

b. Wood Doors:

Install Sleeve onto end of Thermal Pin.

Using wood block as spacer, tap Thermal Pin and Sleeve into 9/16" hole in door edge with hammer.

Note: Reinforcement required where Thermal Pin and Cap Plug are to be installed.

ASSA ABLOY, the global leader in door opening solutions

Copyright © 2008 Corbin Russwin, Inc. All rights reserved. Reproduction in whole or in part without the express written permission of Corbin Russwin, Inc. is prohibited.

In U.S.: Corbin Russwin, Inc.
225 Episcopal Road
Berlin, CT 06037-4004
www.corbinrusswin.com

Technical Product Support:

Phone: 888-607-5703 Fax: 800-659-7293

In Canada: ASSA ABLOY DSS Canada
160 Four Valley Drive
Vaughan, ON, L4K 4T9
www.assaabloycanadadss.ca

**Corbin
Russwin**

ASSA ABLOY

