

Easy Read-Prox® 10 Card Pack

In or Out...we make it Easy!®

This Kit Contains:



10 User Cards with 10 Deletion Cards



1 Enrollment Card

IMPORTANT: Identify user name on matching Deletion Card before removing them from the wallet. Do not mix pairs of cards before writing on Deletion Card. This is a starter pack only. Additional card packs (purchased separately) may be added to your system. Please contact your dealer for more information.

3 Special Function Cards:

FUNCTION CARD door open time card The period that the door is unlocked for wi

1 Door Open Time Card

932-10CP

1. Present this card


- 2. Wait for the required period
- valid token is presented is set as follows: 3. Present this card again, the beeping will stop

FUNCTION CARD fail open release

This card is used with systems where a fail open electric release is used for the safe operation in the event of a fire. Present the card to the reader to drive a fail open release or a maglock. Present the card again to revert to the fail closed operation

1 Fail Open Release Card

FUNCTION CARD silent operation



1 Silent Operation Card

© 2014 RUTHERFORD CONTROLS INT'L I A DORMA GROUP COMPANY WWW.RUTHERFORDCONTROLS.COM • PHONE: 1.800.265.6630 • FAX: 1.800.482.9795 • E-MAIL: SALES@RUTHERFORDCONTROLS.COM